



MISHIMOTO PUSH-LOCK HOSE ASSEMBLY GUIDE

SKU: MMHOSE-PL

ASSEMBLY INSTRUCTIONS

A. Be sure the hose is pushed all the way to the black collar on the push-lock fitting.



Correct



Incorrect

B. Clamps must be used if exposed to temperatures exceeding 140°F and/or pressure exceeding 60psi.



C. For easier installation, follow these steps:

1. Heat a small pot of water to 180°F-200°F.
2. Wear temperature resistant gloves. Place the end of the push-lock hose in the water and hold it under for 30 seconds.
3. Insert fitting into hose and press firmly.

