

# 2018+ HONDA ACCORD 1.5T BAFFLED OIL CATCH CAN, PCV SIDE PARTS LIST & INSTALLATION GUIDE



## PARTS INCLUDED

- 1PC Application-Specific Mounting Bracket
- 1PC Compact Baffled Oil Catch Can
- 4PC Spring Clamps
- 2PC Direct-Fit Hoses w/ Integrated Check Valve
- 2PC 3/8" Aluminum Barbed Fittings  
Mounting Hardware

## TOOLS NEEDED

- 7mm Socket
- 10mm Socket
- 17mm Wrench
- 1/4" Drive Ratchet
- 2.5mm Allen Key
- Pliers

**INSTALL TIME** 30 Minutes

**INSTALL DIFFICULTY**

## DISCLAIMER

- Allow vehicle to cool completely prior to attempting installation.
- Mishimoto is not responsible for any vehicle damage or personal injury due to installation errors, misuse, or removal of Mishimoto products.
- Mishimoto suggests that a trained professional install all Mishimoto products.

## INSTALL PROCEDURE

1. Disconnect the PCV hose from the valve and the intake manifold. (2x spring clamps)



2. Remove the bolts on the fuel line cover. (2x 10mm bolts)



3. Remove the bolts that secure the fuel line bracket. (2x 10mm bolts)



4. Lubricate the three O-rings on the fittings and catch can lid.
5. Thread the fittings onto the catch can. Use a 17mm wrench to snug down the fittings, 1/8 turn only.
6. Slide the catch can bracket behind the fuel line bracket. Secure it with the original hardware. (2x 10mm bolts)



CONTINUED ON FOLLOWING PAGE

# 01

## 2018+ HONDA ACCORD 1.5T BAFFLED OIL CATCH CAN, PCV SIDE INSTALLATION GUIDE



7. Reinstall the fuel line cover. (2x 10mm bolts)
8. Install the catch can to the bracket. (3x 2.5mm Allen bolts)



9. Note the two bigger clamps in your kit. They will hold the hose connections at the catch can.
10. Install the outlet hose to the intake manifold and OUT port on the catch can. The outlet hose is the one with a check valve. (2x spring clamps)



11. Install the inlet hose to the PCV valve and IN port on the catch can. (2x spring clamps)



**Congratulations! You have finished installing the Mishimoto 2018+ Honda Accord 1.5T Baffled Oil Catch Can.**