

2016+ TITAN XD INDUCTION HOSE

PARTS LIST AND INSTALLATION GUIDE



PARTS LIST

1PC | SILICONE INDUCTION HOSE

2PC | WORM-GEAR CLAMPS

TOOLS NEEDED

FLATHEAD SCREWDRIVER

INSTALLATION TIME **LESS THAN 0.5 HR**

INSTALL DIFFICULTY

DISCLAIMER

- Raise vehicle only on jack stands or on a vehicle lift.
- Allow vehicle to cool completely prior to attempting installation.
- Do not run the engine or drive the vehicle while overheating; serious damage can occur.
- Please dispose of any liquids properly.
- Mishimoto is not responsible for any vehicle damage or personal injury due to installation errors, misuse, or removal of Mishimoto products.
- Mishimoto suggests that a trained professional install all Mishimoto products.

INSTALLATION INSTRUCTIONS

01. Disconnect the mass airflow (MAF) sensor. To separate the connector, slide the red locking tab down, then depress the black tab and pull the connector off the sensor.



02. Loosen the clamp that secures the stock intake hose to the airbox. (1x worm-gear clamp)



03. Loosen the clamp that secures the intake hose to the turbo charger inlet. (1x worm-gear clamp)



04. Remove the intake hose from the vehicle by pulling it off the turbocharger inlet and airbox.
05. Slip one of the provided worm-gear clamps over each end of the Mishimoto induction hose, and connect it to the turbocharger inlet and the airbox. Tighten the clamps to secure it. (2x worm-gear clamps)
06. Reconnect the wiring harness to the MAF sensor, and secure the connector with the locking tab

Congrats! You just finished installing the 2016+ Titan XD Induction Hose.

01